Tazio Nuvolari

USER MANUAL





The Eberhard & Co. watch manufactory was founded by Georges-Emile Eberhard at La Chaux-de-Fonds back in 1887. Ever since, the venture has specialised in the making of chronographs.

In this capacity, it has attained a highly respected position in the world of high-grade watches. With the introduction, at a later stage, of sportively elegant watches it has furthermore augmented this status of the Eberhard & Co. brand name.

Eberhard's success story is backed by consistent deployment of advanced technology, meticulous craftsmanship and, not least, by observing that long tradition of superior workmanship which has made Swiss watchmaking a household name.

Today, with well over a century gone by, watches by Eberhard & Co. continue to stand for that high-grade quality and those excellent virtues which will please even the most demanding of connoisseurs.



TAZIO NUVOLARI

The Chronograph that Eberhard & Co. has dedicated to a personality that has become a legend: Tazio Nuvolari, perhaps motor sports' greatest legend of all time. A model, which apart from the personality, celebrates the ingenuity always associated with the great works of great men. "Tazio Nuvolari" is the fruit of a project philosophy, whose reference point is the driver's instrumentation in racing cars of that era: the essential, distinctness, ease of reading in the dark, precision, resistance to bad weather and vibrations. These are the basic requirements of this chronograph. The "Tazio Nuvolari" is embellished and made exclusive by the presence of the legendary small gold tortoise on the left of the dial, the stylised reproduction of the object given to the "Flying Mantovano" by Gabriele d'Annunzio, which became his emblem and is still today the symbol of victory in the world of automobile sports.

INFORMATION REGARDING THE INTERNATIONAL GUARANTEE

We hereby guarantee your Eberhard & Co. watch against any defects in manufacture or materials for a period of 24 months, subject to normal conditions of use.

This quarantee does not cover:

- damage caused by improper technical handling or by shocks
- wear to the strap, glass or any other part during normal watch use.

For technical revisions of the Eberhard & Co. "Tazio Nuvolari" model please contact only technical service facilities authorised by Eberhard & Co. The eventual shipping and insurance charges are to be paid by the owner.

We recommend to have the movement checked and overhauled every two years.

For our part, we shall always endeavour to give full satisfaction.



- A Pushbutton to start and stop the chronograph device
- **B** Pushbutton for setting to zero all hands of the chronograph
- C Screw-in crown, water-resistant
- D Hour hand/watch
- E Minute hand/watch
- F Centre second-hand/chronograph

- G Minute hand/chronograph
- H Hour hand/chronograph
- I Tachometer scale on the dial for speed in kilometres per hour
- L Tachometer scale on the bezel for speed in miles per hour



CHARACTERISTICS

Automatic chronograph movement, 28800 vibrations, shock-resistant, antimagnetic, 25 jewels. Micrometric index (regulator) for fine adjustement of the watch rate. "Glucydur" balance wheel; this regulating part of the movement is made of a stainless alloy for compensating the variations in temperature and it secures the stability of the rate of the watch. Sapphire glass, anti-glare.

DISTINCTIVE FEATURES OF THE MOVEMENT

Our technicians have developed the chronograph device of this particular model for an optimal reading of short time intervals (60 seconds) and long time intervals (minute and hour counters).

Easy reading and high visibility due to the large diameter of the counters.

The "Tazio Nuvolari" model is characterised by the following features:

- luminescent numerals and hands with high visibility
- time-taking to 1/5 of a second
- time-taking of up to 30 minutes
- time-taking of up to 12 hours
- tachometer scale in km/hour on the dial
- tachometer scale in miles/hour engraved on the bezel (1 terrestrial mile = 1609 metres).

The "Tazio Nuvolari" collection comprises wrist and pocket watches, available in following versions:

- case and pushbuttons in high-grade stainless steel, with crocostrap or steel bracelet with clasp featuring a stylised 18 ct. gold reproduction of the mascot tortoise
- case and pushbuttons in 18 carat gold, with crocostrap
- with transparent caseback made of sapphire glass which reveals the movement with its high-grade embellishments. Oscillating weight shows an 18 ct. gold replica of the Alfa Romeo Tipo "C".

The water-resistance is guaranteed up to 3 atm.

The caseback is secured by 8 screws (in gold for the 18 ct. gold model and for the "Gold Car Collection" model) to ensure perfect water-resistance.

The movement of each 18 ct. gold Tazio Nuvolari model has undergone specific tests and received the "chronometer" rating as issued by the "Contrôle Officiel Suisse des Chronomètres" authority. Relevant approval numbering is engraved on the caseback.

USE OF THE CROWN



POSITION A - Screw-in crown. In this position water-resistance guaranteed



POSITION B - To unscrew the crown, turn it counter-clockwise.

Position for hand-winding the movement



POSITION C - Neutral position of the movement



POSITION D - For setting the time

DIRECTIONS FOR USE OF WATER-RESISTANT WATCHES

The "Tazio Nuvolari" model resists unintentional contact with water (rain or small splashes), but it is not fit for swimming, plunging or diving activities. Important: do not pull out the crown nor activate the pushbuttons as long as the watch is wet. We strongly recommend that you have the water-resistance checked at least once a year by a qualified technical service facility in order to find out if the gaskets need to be replaced.



PUSHBUTTONS

Make sure pushbuttons are always pressed in following order:

A: start
A: stop

B: return to zero

Abide by this sequence quite severely so as to preclude damage to the mechanism.

Don't activate the pushbuttons under water since they are not watertight while being pressed.

OPERATING INSTRUCTIONS FOR THE CHRONOGRAPH

Press pushbutton A to start the chronograph. Press it again to stop it. This will make it possible to read the counters (seconds, minutes and hours elapsed). Press pushbutton A again and the chronograph will function again after the intermediate stop. To reset to zero, the chronograph must be in the stop position and, by pressing the second push button B, all the hands will return to zero. You are recommended not to have the chronograph mechanism running constantly.

READING THE TACHOMETER SCALE - TACHOMETER SCALE IN KM/HOUR - BASIS 1000 M - ON THE DIAL

The outer rim on the dial shows the data needed for metering the speed of a vehicle over a distance of 1,000 metres. The moment the vehicle passes the first reading mark, the beginning of said 1,000 m distance, activate the hand ${\bf F}$ of the chronograph to start it and press again to bring it to a stop at the moment the vehicle passes the second reading mark. Said hand ${\bf F}$ will now indicate the average speed reached in km/h in tune with the tachometer scale. Example: when one kilometre is covered within 45 seconds, the average speed displayed by the centre second-hand ${\bf F}$ on the tachometer scale will be tantamount to a speed of 80 km/h.

TACHOMETER SCALE IN MILES/HOUR - BASIS 1000 M - ON THE BEZEL

To measure the speed in miles proceed as explained above for the km/hour, but read the speed in miles on the engraved scale on the bezel of the watch case. Example: if one kilometre is covered in 45 seconds, the average speed indicated by the centre second hand of the chronograph on the tachometer scale is 49.7 miles per hour.



www.eberhard-co-watches.ch